

Sidriste Boljevci/Anchorage Boljevci

Danube km: 19+300 - 19+640

GPS coordinates:

North: 44° 42' 15"

East: 20° 18' 16"

berths information

length: 340 m

river bank

- L left river bank
- R right river bank
- T at the dam

location

- DPP "downstream" side of a power plant
- DL "downstream" side of o lock (lock entrance area)
- UL "upstream" side of a lock (lock entrance area)
- UPP "upstream" side of a power plant
- ARS along the river stretch
- OTH others (before a harbour entrance in an old river branch)

local berths conditions

- 0 berthing permitted (i.e. anchoring or making fast to the bank)
- 1 berthing area reserved for pushing-navigation vessels that are required to carry one blue cone
- 2 berthing area reserved for pushing-navigation vessels that are required to carry two blue cones
- 3 berthing area reserved for pushing-navigation vessels that are required to carry three blue cones
- 4 anchoring permitted
- OTH other restrictions (only for small motor crafts, only for border control, only for damaged vessels after an accident, max. time allowed for berthing,...))

facilities

stairs to go ashore

- yes no

possibility to load and unload cars from a vessel

- yes no

lighting

- yes no

river bank construction

- sheet pile wall
- embankment (slope)
- quay walls
- dam
- dolphins
- pontoon
- natural (wild)

specimen widths

- 1 beam
- 2 beams
- 3 beams
- Width=130m (3 rows with 4 beams each)

connections

ports/harbours in the surrounding area
none

villages, cities in the surrounding area

- < 5 km Umka

access road

- yes no

maintenance and disposal facilities

electricity supply

- yes no

fresh water supply

- yes no

waste disposal

- yes no

petrol station

- yes no

safety in case of flood or storm

- yes no

Parking fees/costs

- yes no

Sidriste Boljevci/Anchorage Boljevci

